

www.BigJoeLift.com

ODEL		
------	--	--

SERIAL

AMPS/HR WEIGHT LBS.





RISK OF SHOCK DO NOT TOUCH

UNINSULATED

TERMINALS OR



Connect BATTERY to CHARGER
(Loose End to Loose End)



DO NOT CONNECT CHARGER to TRUCK (Loose End to Fixed End)

SHIELD NO SULFURIC ACID OF GET CAN CAUSE OF SULFURIC ACID OF SULFURIC ACID

HELP FAST.

KEEP VENT CAPS TIGHTLY IN PLACE,

VENTILATE WELL WHEN IN AN ENCLOSED SPACE AND WHEN CHARGING,

SEE INSTALLATION, MAINTENANCE AND OPERATION INSTRUCTIONS FOR IMPORTANT SAFETY PRECAUTIONS.

REPAIR SHOULD BE PERFORMED ONLY BY A QUALIFIED SERVICE TECHNICIAN.



CALIFORNIA PROPOSITION 65 WARNING:

Batteries, battery posts, terminals and related accessories contain lead and lead compounds, and other chemicals known to the state of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

SAFETY RULES

- When working on batteries, always be careful and always wear Safety Glasses or Face Shield.
- 2) Battery tops should stay clean and dry.
- 3) Electrolyte level in battery check weekly.
- 4) Ensure charger is **OFF** before connection or disconnection of battery to prevent sparks & injury.
- Proper size charger should be used and charger instructions should be read and followed carefully.
- 6) After each duty cycle, Recharge to **FULL**. Avoid recharging to partial capacities.
- 7) CAPS NEED TO STAY ON when battery is being used, charged or when the battery top is being cleaned. Vent Caps should only be removed when checking or filling.
- Steel covered batteries should have covers in open position when recharging.

